

INSTRUCTIONS FOR USE

Please read these instructions and the Options first to get the most from your PRESSAIRE.

To Remove a Clog

1. Clean the rim of toilet if soiled.
2. Unfold and expand PRESSAIRE, with holes facing down place narrow end of PRESSAIRE at the hinge of the toilet seat. Hold the toilet seat and PRESSAIRE as shown to avoid pinching your fingers.

Caution

Just as flushing a toilet when the water level in the toilet bowl is above normal due to a clog can cause the toilet to overflow, rapid compression of PRESSAIRE may generate enough pressure to cause toilets equipped with a flapper valve to flush. To reduce this risk allow the toilet tank to fill completely as the water in the toilet tank holds the flapper valve down. Slowly push PRESSAIRE to expel the excess water in the toilet bowl. Repeat as necessary to lower the water level.

3. While holding PRESSAIRE and the toilet seat push down to compress PRESSAIRE and remove the clog. Repeat if necessary.

Note

If PRESSAIRE easily compresses and does not build up enough pressure to remove the clog. See instructions for *Options.

4. Twist and fold PRESSAIRE and place behind the toilet tank or any other convenient location.

To Clean Your Toilet Bowl

1. Follow steps 1-3 above.
2. With most of the water drained from the toilet add your regular toilet cleaner to the toilet bowl. Less water means your toilet cleaner will be more concentrated to clean your toilet and help remove those stubborn stains.

Note

A slow flushing toilet may be due to mineral buildup deep in the interior of the toilet. Adding additional toilet cleaner will expose more of the interior of the toilet to the concentrated cleaner. This can help dissolve the mineral buildup and improve the toilet flush.



Don't pinch your fingers



Twist and



fold one side under the other



and pull lower end into fold



and press flat to store



* **Options:** PRESSAIRE works with most toilets and clogs by following the instructions above. But just as a regular plunger may not always work, PRESSAIRE may require one or more of the following options to work more effectively. Note: Adding regular liquid dishwashing soap to the toilet bowl can help to remove stubborn toilet clogs.

Option 1 (used when a toilet seat is positioned near the edge of the toilet rim):

1. Fold these instructions lengthwise and place on the toilet rim (a) to allow PRESSAIRE to make a proper seal with the toilet rim..
2. Return to Instructions for Use.



Option 2 (used to partially seal the toilet tank to increase the pressure generated by PRESSAIRE, option 3 may also be used):

1. Remove tank lid. If the top rim of the tank has a notch(s), fold a piece of paper over the notch(s) then place a thick towel over the toilet tank and replace the lid.
2. Return to Instructions for Use.
3. Remove towel and paper
4. Replace tank lid.




Option 3 (use for tough clogs):

1. Remove tank lid. Stuff a rag in the overflow tube. Place PRESSAIRE into position and hold down the toilet flapper valve and push down on PRESSAIRE.

Note

With both the overflow tube plugged and the flapper valve held down, much higher pressures can be generated to remove even some of the toughest clogs, including some clogs previously requiring the use of a plumber's snake or even the services of a plumber. Although this can be performed by one person, it may be easier to have one person hold down the flapper while the other person uses PRESSAIRE. The water in a toilet's tank is fresh water that does not come in contact with the water in the toilet bowl.



2. Repeat if necessary.
3. Release the flapper and remove rag.
4. Replace tank lid.

Note: PRESSAIRE, as with any plunger, will not clear every clog but due to its convenient use with no mess to clean, PRESSAIRE will be your first line of defense when your toilet becomes clogged.

Please visit www.PRESSAIRE.com for additional information.

Dontecor Enterprises, LLC, the makers of Pressaire are not responsible for any damages or losses that may occur from using PRESSAIRE.

Keep out of reach of children.

Made in China